

5" W



PARIS HILTON

6 QT DIGITAL AIR FRYER

CONTROL PANEL QUICK START GUIDE



SCAN THIS QR CODE FOR TIPS AND TRICKS

POWER/START Button

Automatically illuminates red once the Air Fryer is plugged in.

Press the red POWER/START button and the rest of the control panel will appear, and the button will then illuminate white.

Once desired cooking settings are selected, press the white POWER/START button to START the Air Fryer.

Press and hold the white POWER/START button for 2 seconds to power OFF the Air Fryer.


Preset Cooking Options (Not Buttons)

These are not buttons that can be pressed.

Use the MENU button below to access and advance through the options, which will blink once selected.

The selected option will blink until the POWER/START button is pressed to START the Air Fryer. The other preset cooking options will then disappear and only the cooking option selected will remain illuminated.

7" H



TEMP - UP & DOWN Arrow Buttons

Press the UP or DOWN arrow buttons to increase or decrease the cooking temperature.

TIME - UP & DOWN Arrow Buttons

Press the UP or DOWN arrow buttons to increase or decrease the cooking time.

MENU Button

Press the MENU button to access and advance through the 8 preset cooking options. Press once for the AIR FRY option, twice for ROAST, etc.